
SIGMA

SIGMA MACRO 50mm F/2.8

Instructions

Thank you for purchasing this Sigma lens. Please read the following instructions carefully so that you can obtain the maximum enjoyment and performance from your new lens.



Operation

- 1. Attach the lens to the camera body.
- 2. Turn the aperture ring to the center line on top of the lens to set the appropriate aperture in relation to the shutter speed selected.
- Look into the viewfinder, turn the focus control ring until the image is sharp.

Depth-of-Field

This depth-of-field is indicated on the barrel of all Sigma Lenses, including zoom lenses. You can read the depth-of-field on the distance scale.

What is the ratio indicator?

This is the scale which shows the ratio between actual subject size and the size of the image as it appears on the film, i.e.: if the 1:1 position is used, then the subject will be photographed at 1/1 th of its actual size.

Sigma 50 mm F/2.8

- Lens Construction:10 elements in 9 groups.
- Angle of View:48° Minimum Aperture:F/22 ● Minimum Focusing Distance:19cm (approx.7.4inches)
- Magnification: 1:1
- Filter Size:52mm Dimensions: 66.5mm×59.5mm(2.5×2.3inches)
- Weight:320g(11.2oz.)
- Lens Coating:Sigma Multi-Coating.